



azienda chimica e farmaceutica

SPECIFICA TECNICA

Prodotto **DRY FLO P C**

NOME INCI ALUMINUM STARCH OCTENYLSUCCINATE
NOME INCI USA ALUMINUM STARCH OCTENYLSUCCINATE

SPECIFICA	METODO	Lim. Inf. - Lim. Sup.	u.m.
* Aspetto		Polvere di colore bianco o biancastro scorrevole, praticamente priva di corpi estranei.	
pH (in H ₂ O/Amido 4/1)		4,50 - 7,00	
Ceneri totali		<=0,70	%
Identificazione IR		Positiva	
Umidità		<=14,0	%
Granulometria (attraverso 100 mesh)		>=99,5	%
<i>Specifiche microbiologiche</i>			
- Coliformi		<=50	CFU/g
- E.coli		Negativo	
- Muffe		<=250	CFU/g
- Salmonella		Negativo	
- Conta batterica totale		<=2.000	CFU/g
- Lieviti		<=250	CFU/g
Revisione Capitolato		1	
Data Approvazione		13/02/2013	

* saggi non obbligatori

Gli eventuali metodi d'analisi non riportati sono metodi interni del produttore ottenibili su specifica richiesta

Le informazioni sopra riportate non Vi sollevano dall'obbligo di identificare il prodotto prima dell'impiego. La nostra società non si assume alcuna responsabilità per danni a persone o cose derivanti dall'impiego dei prodotti da noi commercializzati



azienda chimica e farmaceutica

SPECIFICA TECNICA

Prodotto **DRY FLO P C**

Moisture is measured on a Cenco Moisture Balance.

The pH is measured by preparing a slurry of 20 parts of the product in 10 parts 200 proof (anhydrous) ethanol to which is added 70 parts deionized water. Denatured ethanol should not be used.

DRY-FLO® PC is a unique, hydrophobically modified natural polymer. Supplied as a free flowing white powder, DRY-FLO PC displays a unique combination of properties that makes it well suited for use in a wide variety of personal care products.

Because of its smooth, velvety feel properties, DRY-FLO PC can be used in various powder applications. The starch based product can be utilized as a talc replacement in body powders, adsorbing moisture without caking. In antiperspirants, DRY-FLO PC enhances the visual whiteness of a stick, for example, without contributing to whitening upon application to the skin. In color cosmetics, DRY-FLO PC can be incorporated into liquid or powdered make-up products to improve the aesthetics of the formulation and to adsorb excess oil from skin. Perhaps the most distinctive property of this remarkable product is its unique ability to mitigate the greasiness produced by occlusive agents used in lotions, creams and ointments. In both aqueous and anhydrous products for skin care, DRY-FLO PC reduces the perceived oiliness of formulations, leaving a soft, dry and matte finish on the skin. Because the starch has a broad incorporation range, the amount of DRY-FLO PC can be adjusted for very specific formulation aesthetics. Sunscreens can also benefit from the addition of DRY-FLO PC to the formula. The starch can improve tactile properties, reduce rub-off and enhance SPF - all without whitening on the skin.

APPLICATION AREAS

Powders, Color Cosmetics, Lotions, Ointments, Creams, Antiperspirants, Sunscreens, Deodorants, Dry Shampoo, Pomades

FEATURES/BENEFITS

- Soft, velvety feel
- Hydrophobic
- Oil adsorbent
- Natural polymer
- Free flowing/anti-caking
- Fine, uniform particle size
- Easy to use
- Environmentally friendly
- Improves aesthetics and mitigates greasiness of lotions, creams and ointments
- Enhances SPF of sunscreens
- Improves aesthetics and flow properties of powders
- Does not whiten on skin

FDA Status:

DRY-FLO PC is acceptable for use in food and is covered by regulation 121.1031 for food starch modified. (Irradiated version)

FORMULATION GUIDELINES

DRY-FLO PC is commonly used as an aesthetics modifier in aqueous emulsions as well as in anhydrous



azienda chimica e farmaceutica

SPECIFICA TECNICA

Prodotto **DRY FLO P C**

ointment formulations. The method of incorporation, which is especially important when adding the starch to an aqueous emulsion, is detailed below:

Aqueous Emulsions

DRY-FLO PC is hydrophobic and thus is not wetted by water alone. The preferred method of incorporation into an emulsion is to wet out the starch in water soluble humectants or in oils. Post add the slurry to the emulsion below 45°C, on cool down. The DRYFLO PC can be added as a powder directly to the emulsion with proper mixing. Again, care must be taken to incorporate the starch at 45°C or below when used in aqueous systems. If temperatures above 50°C are encountered, the starch granule begins to partially solubilize, reducing its effectiveness as an aesthetics control agent.

Anhydrous Ointments

Combine all ingredients, except for DRY-FLO PC and heat to melting. Mix until homogeneous. Slowly sift in the DRY-FLO PC and mix until uniform. Maintain temperature above the melting point of the combined oleaginous materials; the starch will remain in the system as a particulate. Note that the temperature constraint outlined for aqueous emulsions does not apply in anhydrous systems. The DRY-FLO PC will be unaffected up to 80°C in non-aqueous formulations.

Once added to either an aqueous emulsion or an anhydrous product, the DRY-FLO PC can be homogenized or milled without affecting its properties.

Because DRY-FLO PC is an organic material, it is susceptible to bacteriological attack. Suitable preservation is recommended for systems containing DRY-FLO PC.

TESTS AND METHODS

1. Greasiness Mitigation: In a blind panel test involving 20 participants, the anhydrous ointment described below was overwhelmingly selected as being far less greasy than the same formula control without DRY-FLO PC.

Petrolatum 35.00
Cocoa Butter 5.00
DRY-FLO PC 60.00

2. Non-whitening: Using the same formula above, panelists found that it produced a clear, translucent coating on the skin. Whitening was not perceived in spite of the relatively high loading of the DRY-FLO PC in the ointment. In addition, actual reflectance measurements were performed on swatches of natural worsted wool which had been uniformly coated with lotions containing DRY-FLO PC or micronized titanium dioxide. Higher reflectance values relate to greater perceived whiteness on skin. Reflectance was measured directly using a model Micro S-5 Brightmeter manufactured by Technidyne Corp., New Albany, IN.

Formula	Pigment	%Reflectance _	vs Control
Control (fabric only)	0	45.7	-
Lotion only	0	54.6	+8.9
Lotion + DRYFLO PC	10%	51.7	+6.0
Lotion + micronized TiO2	5%	66.5	+20.8
Lotion + micronized TiO2	10%	73.2	+27.5

Substantially less reflectance was measured with 10% DRY-FLO PC than with formulas tested which contained micronized titanium dioxide.



azienda chimica e farmaceutica

SPECIFICA TECNICA

Prodotto **DRY FLO P C**

3. SPF Enhancement: DRY-FLO PC has shown the ability to enhance the SPF of sun care products, which are based on various types of sunscreens. DRY-FLO PC can be used in combinations with micronized titanium dioxide to produce non-greasy, more cost efficient, higher SPF lotions and creams, which will not whiten when applied to the skin.

To exemplify, standard sunscreen lotions were prepared with 1% and 2% micronized TiO₂. A third lotion contained 5% DRY-FLO PC in the same base in combination with 1% TiO₂. In vivo SPF testing was performed on each of the sunscreen formulations. Data is outlined below. Note the higher SPF with the formula containing DRY-FLO PC.

% % Mean

Formulation	TiO ₂	DRY-FLO PC	SPF
Base Formula	1%	0	5.6
Base Formula	1%	5	8.1
Base Formula	2%	0	9.8

HANDLING AND STORAGE

DRY-FLO PC is a finely divided organic particulate. When handling, avoid generation of dust. Use in well ventilated area. Use of a dust mask is suggested. Exercise good housekeeping practices. Avoid contact of the DRY-FLO PC powder or dust with heat, sparks or open flame.

Gli eventuali metodi d'analisi non riportati sono metodi interni del produttore ottenibili su specifica richiesta

Le informazioni sopra riportate non Vi sollevano dall'obbligo di identificare il prodotto prima dell'impiego. La nostra società non si assume alcuna responsabilità per danni a persone o cose derivanti dall'impiego dei prodotti da noi commercializzati